



Installation Instructions for AFCO Detented Weight Jack Plate

#20193D

Installation procedure

- 1) Weld plate into position on chassis. Make sure to orient the grease fitting and detent holes for easy access.
- 2) Install grease fitting into 1/4-28 threaded hole.
- 3) Install 20194-LW weight jack bolt (not included) into 20193D plate.
- 4) Place 7/32" ball into opposite hole as shown in picture.
- 5) Place spring into hole over top of the ball.
- 6) Apply thread locking compound to threads of set screw. Screw into hole until face is flush with surface.
- 7) Adjust screw in or out until desirable "click" feel is achieved.

